

Calibration Method for the Tecsun S-2000

NB this procedure is only valid for receivers with software version 2009 and above.

Follow the below steps to check on the version # of S2000:

1. Press "Sys set"
2. Press 2 2
3. Press "enter" then the display will show out the version #.

For FM, please follow these steps:

1. Tune into the FM frequency that requires alignment;
2. Press & hold the SSB button until the backlight starts flashing rapidly;
3. Rotate the tuning knob until the signal becomes clearer, then press the 1 key to confirm the calibration.

For AM and SW, please follow these steps:

- 1) Tune into the frequency where you would expect the station to be located. For example, 702 kHz.
- 2) Now press and hold the AIR button until the backlight starts flashing rapidly.
- 3) Now tune into the frequency where the reception is clearest, in this example 702 kHz.
- 4) Then press 1 to confirm the setting.

It may be necessary to follow these steps for both the narrow bandwidth and the wide bandwidth.